


На световую панель управления (CONTROL BOARD)

P.ON-10V	1	P.ON-10V
LCD-10V	2	LCD-10V
LCD-10V	3	LCD-10V
LCDCLK	4	LCDCLK
LCDINH	5	LCDINH
LCDSD	6	LCDSD
SIRCS	7	SIRCS
DOOR	8	DOOR-SW
HO	9	KEY-IND
W1	10	KEY-INT
COLOR	11	COLOR
COLOR	12	COLOR
DIMMER	13	NC
DIMMER	14	NC
DIMMER	15	DIMMER
DIMMER	16	GND



К. СОВМЕСТНОЕ ИСПОЛНЕНИЕ (MIXED BOARD) CN18001

14	ГND
13	DIMMER
12	DOOR-SW
11	NC
10	COLOR
9	KEY1IN
8	KEY1IN
7	LCD50
6	SIRCS
5	LCCDLO
4	LCCDINH
3	LCCDF
2	LCD-10V
1	P.ON-10V

Схема управления ЖКД LC75824W

ЖКД LCDR01

Пульт управления